

## Starter kit accessories DLS/FLS

Part No. 500590



The Starter Kit accessories from Dimetix AG help you to become familiarised with DLS/FLS Distance Laser Sensors. The kit includes all necessary components to operate a DLS/FLS sensor.

### Contents

- 1 RS-232 configuration cable (500200) for connecting the DLS/FLS sensor to a PC via a RS-232 serial interface
- 1 Power supply with worldwide usage possible due to wide range input - 100 to 240 VAC - and primary plug system
- 1 CD-ROM with DIMETIX utility software
- 1 DLS/FLS manual

### System requirements

- PC system software must support .NET Framework
- RS-232 serial interface
- In case of only a USB interface on the PC, use the USB/RS-232 converter (500209)

### Order information

| Part No. | Description  |
|----------|--|
| 500590   | <p>Starter kit accessories DLS/FLS</p> <p>Consisting of:</p> <ul style="list-style-type: none"> <li>• RS-232 configuration cable (500200)</li> <li>• Power Supply<br/>IN: 100 ... 240 VAC, 0.6A<br/>Out: 24 VDC, 0.75 A<br/><b>Not applicable for measuring devices with the heater!</b></li> <li>• DLS/FLS Utility Software</li> <li>• DLS/FLS Manual</li> </ul> <p><b>DLS/FLS Laser Distance Sensor must be ordered separately</b></p> |

